

**DIGITAL CONTROLLER WITH ADVANCED ENERGY SAVING MANAGEMENT**  
**XRBO4CX**

1 GENERAL WARNINGS .....1  
 2 GENERAL DESCRIPTION .....1  
 3 REGULATION .....1  
 4 ENERGY REDUCTION ALGORITHM .....1  
 5 EXTRA COOLING FUNCTION .....2  
 6 DEFROST .....2  
 7 INTERNAL COUNTERS .....2  
 8 FRONT PANEL COMMANDS .....2  
 9 PARAMETERS .....3  
 10 DIGITAL INPUT .....4  
 11 INSTALLATION AND MOUNTING .....4  
 12 OPTIONAL FEATURES .....4  
 13 ELECTRICAL CONNECTIONS .....4  
 14 USE THE HOT KEY .....4  
 15 USE THE PROG-KEY .....4  
 16 ALARM SIGNALLING .....4  
 17 TECHNICAL DATA .....4  
 18 CONNECTIONS .....5  
 19 DEFAULT SETTING VALUES .....5

**1 GENERAL WARNINGS**

**1.1 PLEASE READ BEFORE USING THIS MANUAL**

- This manual is part of the product and should be kept near the instrument for easy and quick reference.
- The instrument shall not be used for purposes different from those described hereunder. It cannot be used as a safety device.
- Check the application limits before proceeding.
- Dixell S.r.l reserves the right to change the composition of its products, even without notice, ensuring the same and unchanged functionality.

**1.2 SAFETY PRECAUTIONS**


- Check the supply voltage is correct before connecting the instrument.
- Do not expose to water or moisture: use the controller only within the operating limits avoiding sudden temperature changes with high atmospheric humidity to prevent formation of condensation
- Warning: disconnect all electrical connections before any kind of maintenance.
- Fit the probe where it is not accessible by the End User. The instrument must not be opened.
- In case of failure or faulty operation send the instrument back to the distributor or to "Dixell S.r.l." (see address) with a detailed description of the fault.
- Consider the maximum current which can be applied to each relay (see Technical Data).
- Ensure that the wires for probes, loads and the power supply are separated and far enough from each other, without crossing or intertwining.
- In case of applications in industrial environments, the use of mains filters (our mod. FT1) in parallel with inductive loads could be useful.

**2 GENERAL DESCRIPTION**

The XRBO4CX, 32x74x60mm format, is a microprocessor based controller suitable for applications on medium or low temperature ventilated refrigeration units. It has 2 relay outputs to control compressor and an auxiliary output. The device is also provided with up to 3 NTC probe inputs: the first one for temperature control, the second one to be located onto the evaporator to control the defrost termination temperature and to manage the fan and the third, optional and located on the HOT-KEY port, used to control the condenser temperature. There is also a configurable digital input. By using the HOT-KEY it is possible to program the instrument in a quick and easy way.

**3 REGULATION**

The regulation is performed according to the temperature measured by the thermostat probe with a positive differential from the set point: if the temperature increases and reaches set point plus differential, the compressor will start. The compressor will stop when the temperature reaches the set point value again.



In case of fault because of the thermostat probe, the start and stop of the compressor are timed through parameters CoF and Con.

**4 ENERGY REDUCTION ALGORITHM**

**4.1 DESCRIPTION**

The device permits to set different temperature to be used during normal and reduced power use. The standard SET-POINT (SET) is used to maintain the temperature at a certain value when the energy saving status (ES) is not active. On the other side, when the ES status is active a different SET-POINT (SET\_ES), higher than the standard one, will be used. The parameter HES will have to be set to change the regulation temperature according to the following formula:

$$SET\_ES = SET + HES$$

There are also two different differential values for SET and SET\_ES, which are used for compressor cut-in and cut-out: when ES status is active the HYE parameter will be used instead of the HY parameter.

The device uses special Energy reduction Algorithm (ErA algorithm from Dixell) to optimize loads activation during the day. It is possible to set two different algorithms (ErA=bAS or Aut). They differ for the used sensor and for the total length of the interval of time involved.

**4.2 BASIC ENERGY SAVING ALGORITHM – ErA=bAS**


This will be used when ErA=bAS. The energy saving status will be always saved in the internal memory to resume previous operation if a power failure occurs. It needs the presence of a door switch to work (i1F=dor).

**4.2.1 Parameter involved and suggested values:**

- ErA=bAS
- i1F=dor
- StE=4.0 hours
- EtS=6.0 hours
- HES=4.0 to 5.0 °C
- HYE=3 to 4°C
- dS=5 to 10 sec
- LdE=Y

FROM	TO	CHANGED BY
Normal mode	Energy Saving	- Push the DOWN button for 3 sec (if enabled). - Door continuously closed for the StE time.
Energy Saving	Normal mode	- Push the DOWN button for 3 sec (if enabled). - Controller in ES mode for the EtS time. - If the controller is in ES mode, it returns in Standard mode (normal set-point) after opening the door more than dS time.

**NOTE:** the cycling mode (ES - Normal mode - ES - etc.) works if i1F=dor and EtS and StE are different from zero. If EtS=0 or StE=0, the controller will not change the operating mode, and it will be possible to change from the normal mode to the energy saving mode by using ES button or by setting i1F=ES. See the below diagrams where the status changing is depicted:



**4.3 AUTOMATIC ENERGY SAVING ALGORITHM**

This will be used when ErA=Aut. The operations are controlled by using the Aid parameter. After powering on the device, it automatically starts to analyze the temperature behavior by using the only room temperature probe. In this way it can build the best energy saving model according to the application. The device uses temperature behavior information of the previous Aid interval to manage the loads during the current period. When Aid is set to use long periods (Aid>1), a day-by-day model will be used during the first interval of time.


**4.3.1 Parameter involved and suggested values:**

- ErA=Aut
- Aid=1 or 7
- LdE=Y
- HES= 4.0 to 5.0°C
- HYE=3 to 4°C

**NOTES:**

1. In case of any blackout, the calculated energy saving model will be reset.
2. ErA can exclusively drive the light output by using the LdE parameter. When LdE=YES, the light output status will change according to the energy saving (ES) status:
  - a. OFF if ES is active
  - b. ON if ES is not active
3. It is always possible to override the light output status by using the frontal button. Anyway, this modification will have a temporary impact on the lights if LdE=YES. In fact, ErA will take the control after the next ES status change.
4. ErA does not need any door switch input to work.
5. Be sure to place the room temperature probe in near the upper zone of the cabinet: this gives the best results in terms of temperature variation analysis.
6. The Aid parameter indicates the interval of analysis as "number of days". The suggested values for it are 1 or 7, depending on the particular application.
7. When Aid=1, the first day will be used to analyze the temperature behavior and to build the model to apply to the second day. The model will be updated every day in order to better match the working conditions.
8. When Aid=7, the first 7 days will be used to analyze the temperature behavior and to build the model to apply to the next 7 days. The model will be updated every 7 days in order to better match the working conditions.
9. When Aid=7, the first 7 days after power on will use a sub analysis base on 1-day model.

**5 EXTRA COOLING FUNCTION**



The SUPER-COOLING function is active when the room temperature measured from the probe 1 goes over the **SET+oHt+HY** value. In this case, a special set-point value, lower than the normal SET value, will be enabled. As soon as the room temperature reaches the **SET-SCo** value, the compressor will be stopped and the normal regulation will restart. **N.B.:** super-cooling function is disabled when **SCo=0**. The **tSc** parameter sets the maximum activation time for super cooling operations. When **tSc** expires, the super cooling will be stopped and the standard SET-POINT will be restored. **NOTE:** in case of energy saving mode active, the used values will be: **SET\_ES=SET+HES, oHE** and **SCE**.

**6 DEFROST**

**6.1 DEFROST MODE**

Any defrost operation can be controlled in the following way:

- **EdF=rtC:** by using an internal real time clock (only for models equipped with RTC).
- **EdF=in:** timed defrost, in this case a new defrost will start as soon as the **idF** timer elapses.
- **EdF=Aut:** automatic management, in this case the controller will start a new defrost any time a change from normal to energy saving mode will occur (valid if **ErA=Aut**).

**6.2 TIMED OR PROBE CONTROLLED MODE**

Two defrost modes are available: timed or controlled by the evaporator's probe. A couple of parameters is used to control the interval between defrost cycles (**idF**) and its maximum length (**MdF**). During the defrost cycle is possible to select some different display indications by using the **dFd** parameter. These modes are available with any kind of defrost type:

- **tdF=EL:** electric heater defrost;
- **tdF=in:** hot gas defrost;

**6.3 AUTOMATIC DURATION DETECTION**

When a defrost operation is performed by compressor stop (means by stopping the compressor and by activating the internal ventilators), it will be possible to use an automatic defrost mode by setting **tdF=ALt**. In this case the device will use the evaporator probe (which **MUST** to be present and properly mounted on the evaporator surface) to detect the end of the actual defrost phase. In any case, a maximum period of time (**MdF**) and an upper evaporator temperature value will be used to stop the current defrost phase. If **ErA=Aut**, the automatic defrost mode will activate a defrost at the beginning of any energy saving mode period. In this case the **idF** value is used as safety function. It forces the controller to activate a defrost operation when **idF** runs. **NOTE:** during the defrost phase the loads (compressor and evaporator fans) will be controlled from the defrost algorithm.

**7 INTERNAL COUNTERS**

The next table shows the implemented load and function counters.

n1H	Number of compressor activation (thousands of)
n1L	Number of compressor activation (hundreds of)
n4H	Number of light activation (thousands of)
n4L	Number of light activation (hundreds of)
oCH	Compressor working hours (thousands of)
oCL	Compressor working hours (hundreds of)

In this way it is possible to monitor the application and discovering bad functioning that could lead to damages. They are updated in EEPROM every hour. It is not possible to reset them.

**NOTE:** the compressor activation counters take into account also defrost in case of inversion (hot gas) mode.

**7.1 AUX RELAY CONFIGURATION (PAR. oA3)**

The functioning of the auxiliary relay can be set by the **oA1** parameter, according to the kind of application. In the following paragraph the possible setting:

**7.1.1 Light relay**

With **oA3=LIG** the AUX relay operates as light output.

**7.1.2 Auxiliary relay**

Relay activation by digital input 1 or digital input 2 (**oA3=AUS, i1F** or **i2F=AUS**): with **oA3=AUS** and **i1F, i2F=AUS** the AUX relay is switched on and off by digital inputs.

**7.1.3 On/off relay (oA3 = onF)**

When **oA3=onF**, the AUX relay is activated when the controller is turned on and de-activated when the controller is turned off.

**7.1.4 Alarm relay**

With **oA3=ALr** the AUX relay operates as alarm relay. It is activated every time an alarm happens. Its status depends on the **tbA** parameter: if **tbA=Y**, the relay is silenced by pressing any key. If **tbA=n**, the alarm relay stay on until the alarm condition recovers.

**7.1.5 Activation during energy saving cycles**

With **oA3=HES**, the AUX relay is energised when the energy saving cycle is activated.

**8 FRONT PANEL COMMANDS**



<b>SET</b>	Press to display target set point and the real set point. When in programming mode it selects a parameter or confirms an operation
	(LIG) To switch on and off the light
	(DEF) To start a defrost (when function available)
	(UP) In programming mode it browses the parameter codes or increases the displayed value.
	(DOWN) In programming mode it browses the parameter codes or decreases the displayed value.
	(ONOFF) Keep it pressed for 3 sec to activate or to deactivate the key function (see par. onF)

**KEYS COMBINATION**

	To lock or unlock the keyboard
<b>SET</b> +	To enter in programming mode
<b>SET</b> +	To return to room temperature display

ICON	MODE	MEANING
	On	Compressor enabled
	Flashing	Anti-short cycle delay enabled (AC parameter)
	On	Light output enabled
	On	Fans output enabled
	Flashing	Fans delay after defrost
	On	Measurement unit
	Flashing	Programming mode
	On	Energy saving mode active
	On	An alarm condition is present
	Flashing	Start-up operations are pending

**NOTE:** start-up operations lasts about 30 sec after powering on the device. At the end of this phase, the alarm icon will switch off if no alarm is active.

**8.1 SET POINT MENU**

The **SET** key gives access to a quick menu where it is possible to see:

- the set point value;
- the real set point value (**rSE**).

Push and release the **SET** key five times or wait for 60 sec to return to normal visualisation.

**8.2 CHANGE THE SETPOINT**

1. Push the **SET** key for more than 2 sec to change the Set point value;
2. The value of the set point will be displayed and the "°C" LED starts blinking;
3. To change the Set value push the **UP** or **DOWN** button.
4. To memorise the new set point value push the **SET** key again or wait for 60 sec.

**8.3 HOW TO: START A MANUAL DEFROST**

Push the **DEFROST** button for more than 2 sec to start a manual defrost.

**8.4 HOW TO: CHANGE A PARAMETER VALUE**

To change the parameter values operate as follows:

1. Enter the Programming mode by pressing the **SET+DOWN** buttons for 3 sec ("°C" LED starts blinking).
2. Select the required parameter. Press the **SET** button to display its value
3. Use **UP** or **DOWN** buttons to change its value.
4. Press **SET** to store the new value and move to the following parameter.

**To exit:** Press **SET+UP** buttons or waits for 15 sec without pressing any key.

**NOTE:** the set value is stored even when the procedure exits by waiting the time-out to expire.

**8.5 HOW TO: SHOW THE HIDDEN MENU**

The hidden menu includes all the parameters of the instrument.

**ENTER THE HIDDEN MENU**

1. Enter the Programming mode by pressing **SET+DOWN** buttons for 3 sec ("°C" or "°F" LED starts blinking).
2. Released the keys and then push again **SET+DOWN** buttons for more than 7 sec. The "L2" label will be displayed immediately followed from the **HY** parameter.  
**NOW YOU ARE IN THE HIDDEN MENU.**
3. Select the required parameter.
4. Press the **SET** key to display its value

- Use UP or DOWN to change its value.
- Press SET to store the new value and move to the following parameter.

To exit: Press SET+UP or wait for 15 sec without pressing any key.

NOTE1: if there are no parameters in L1, after 3 sec the "nP" label will be displayed. Keep the keys pushed till the "L2" message will be displayed.

NOTE2: the previous set value will be stored even if the programming mode exits by waiting for the time-out to expire.

**MOVE PARAMETERS FROM THE HIDDEN MENU TO THE FIRST LEVEL AND VICEVERSA.**

Each parameter present in the HIDDEN MENU can be removed or put into "THE FIRST LEVEL" (user level) by pressing SET+DOWN. If a parameter is visible also in the First Level, in the HIDDEN MENU the decimal point will be lit.

**8.6 HOW TO: LOCK THE KEYBOARD**

- Keep both UP and DOWN buttons pressed for more than 3 sec.
- The "oFF" label will be displayed and the keyboard will be locked. If any button is pressed more than 3 sec, the "oFF" message will be displayed.

**8.7 HOW TO: UNLOCK THE KEYBOARD**

Keep both UP and DOWN buttons pressed together for more than 3 sec till the "on" message will be displayed.

**9 PARAMETERS**

**REGULATION**

HY	Differential in normal mode (energy saving not active): (0.1 to 25.0°C; 1 to 45°F) differential for set point. Compressor Cut-IN is [SET-POINT + HY]. Compressor Cut-OUT is when the temperature reaches the set point.
HYE	Differential when energy saving mode is active: (0.1 to 25.0°C; 1 to 45°F) differential for set point. Compressor Cut-IN is [SET-POINT + HES + HYE]. Compressor Cut-OUT is when the temperature reaches the [SET-POINT + HES].
LS	Minimum SET POINT: (-55.0°C to SET; -67°F to SET) sets the minimum value for the set point.
US	Maximum SET POINT: (SET to 110.0°C; SET to 230°F) set the maximum value for set point.
ot	Thermostat probe calibration: (-12.0 to 12.0°C; -21 to 21°F) allows to adjust any possible offset of the first probe.
P2P	Evaporator probe presence: n = not present; Y = the defrost stops by temperature.
oE	Evaporator probe calibration: (-12.0 to 12.0°C; -21 to 21°F) allows to adjust any possible offset of the second probe.
P4P	Fourth probe presence: n = not present; Y = the condenser temperature alarm is managed.
o4	Fourth probe calibration: (-12.0 to 12.0°C; -21 to 21°F) allows to adjust any possible offset of the condenser probe.
odS	Outputs activation delay at start up: (0 to 255 min) this function is enabled after the start up of the instrument and inhibits any output activation for the period of time set in the parameter.
AC	Anti-short cycle delay: (0 to 50 min) minimum interval between a compressor stop and the following restart.
Con	Compressor ON time with faulty probe: (0 to 255 min) time during which the compressor is active in case of faulty thermostat probe. With CY=0 compressor is always OFF.
CoF	Compressor OFF time with faulty probe: (0 to 255 min) time during which the compressor is OFF in case of faulty thermostat probe. With Cn=0 compressor is always active.

**DISPLAY**

CF	Temperature measurement unit: (°C; °F) °C = Celsius; °F = Fahrenheit.
rES	Resolution (only for °C): (dE; in) dE = decimal; in = integer.
Lod	Local display visualization: P1; P2; P3 (not used); P4; SET; dtr (not used); USr (not used)
dLY	Display temperature delay: (0.0 to 20min00sec, res. 10 sec) when the temperature increases, the display is updated of 1°C or 1°F after this time.

**DEFROST**

tdF	Defrost type: EL=electrical heaters; in=hot gas; ALT=compressor stop defrost mode.
dFP	Probe selection for defrost control (termination): nP=no probe; P1=thermostat probe; P2=evaporator probe; P3=third probe; P4=Probe on Hot Key plug.
dtE	Defrost termination temperature: (-55 to 50°C; -67 to 122°F) it sets the temperature measured by the evaporator probe (dFP), which causes the end of defrost.
idf	Interval between two consecutive defrost cycles: (0 to 255 hours) determines the time interval between the beginnings of two defrosting cycles.
MdF	Maximum length for defrost: (0 to 255 min; 0 means no defrost) when P2P=n (no evaporator probe presence) it sets the defrost duration, when P2P=Y (defrost end based on evaporator temperature) it sets the maximum length for defrost.
dFd	Display during defrost: (rt; it; SP; dF) rt = real temperature; it = start defrost temperature; SP = SET-POINT; dF = label "dF".
dAd	Max delay for updating display after a defrost: (0 to 255 min) delay before updating the temperature on the display after finishing a defrost.
Fdt	Draining time: (0 to 255 min)
dPo	First defrost after start-up: (n; Y) to enable defrost at power on.
dAF	Defrost delay after freezing: (0.0 to 24h00min, res. 10 min) delay before activating a defrost.

**ALARMS**

ALC	Temperature alarms configuration: (Ab, rE) Ab = absolute; rE = relative. Maximum temperature alarm: when this temperature is reached, the alarm is enabled after the Ad delay time.
ALU	<ul style="list-style-type: none"> <li>If ALC=Ab → ALL to 110.0°C or ALL to 230°F.</li> <li>If ALC=rE → 0.0 to 50.0°C or 0 to 90°F.</li> </ul>
ALL	Minimum temperature alarm: when this temperature is reached, the alarm is enabled after the Ad delay time. <ul style="list-style-type: none"> <li>If ALC=Ab → -55.0°C to ALU or -67°F to ALU.</li> <li>If ALC=rE → 0.0 to 50.0°C or 0 to 90°F.</li> </ul>
AFH	Differential for temperature alarm recovery: (0.1 to 25.0°C; 1 to 45°F) differential for alarms.
ALd	Temperature alarm delay: (0 to 255 min) delay time between the detection of an alarm condition and the relative alarm signalling.
dAo	Delay of temperature alarm at start up: (0.0 to 24h00min, res. 10 min) delay time between the detection of a temperature alarm condition and the relative alarm signalling, after powering on the instrument.

**CONDENSER TEMPERATURE ALARM**

AP2	Probe selection for second temperature alarms: (nP; P1; P2; P3; P4) nP=no probe; P1=thermostat probe; P2=evaporator probe; P3=do not use it; P4=Probe on Hot Key plug
AL2	Second low temperature alarm: (-55.0 to 110.0°C; -67 to 230°F)
AU2	Second high temperature alarm: (-55.0 to 110.0°C; -67 to 230°F)
AH2	Differential for second temperature alarm recovery: (0.1 to 25.0°C; 1 to 45°F)
Ad2	Second temperature alarm delay: (0 to 255 min; 255 = not used) delay time between the detection of a condenser alarm condition and the relative alarm signalling.
da2	Delay for second temperature alarm at start up: (0.0 to 24h00min, res. 10 min)
bLL	Compressor off because of second low temperature alarm: (n; Y) n = no, compressor keeps on working; Y = yes, compressor is switched off till the alarm is present, in any case regulation restarts after AC time at minimum.
AC2	Compressor off because of second high temperature alarm: (n; Y) n = no, compressor keeps on working; Y = yes, compressor is switched off till the alarm is present, in any case regulation restarts after AC time at minimum.
tbA	Alarm muting: (n; Y) to mute the (optional) buzzer and the output configured as alarm.

**DIGITAL OUTPUT MANAGEMENT**

oA3	Relay configuration: (dEF; FAn; ALr; LiG; AUS; onF; db; dEF2; HES) dEF = defrost; FAn = do not select it; ALr = alarm; LiG = light; AUS = Auxiliary relay; onF = always on with instrument on; db = do not select it; dEF2 = do not select it; HES = energy saving output.
-----	--

**DIGITAL INPUT**

i1P	Digital input 1 polarity: (oP; CL) oP = activated by closing the contact; CL = activated by opening the contact. Digital input 1 configuration: (dor; dEF; LiG; AUS; Lis; ES) <ul style="list-style-type: none"> <li>dor = door switch function;</li> <li>dEF = defrost activation;</li> <li>LiG = light activation / deactivation;</li> <li>AUS = not used;</li> <li>Lis = not used;</li> <li>ES = energy saving activation / deactivation.</li> </ul>
i1F	Digital inputs alarm delay: (0 to 255 min) when i1F=EAL or bAL, it is the delay between the detection of an external alarm condition and the relative signalling. When i1F=dor, this represents the delay before the activation of the door open alarm.
did	Door alarm delay: (0 to 255 min)
doA	Compressor and fan status after opening of the door: (no; FAn; CPn; F-C) no = normal; FAn = Fans OFF; CPn = Compressor OFF; F-C = Compressor and fans OFF.
odC	Regulation restart after door open alarm: (n; Y) n = no regulation if door is opened; Y = when did is elapsed, regulation restarts even if a door open alarm is present.

**ENERGY SAVING**

ErA	Energy reduction algorithm used: (nu; bAS; Aut) nu=no energy saving algorithm used; bAS=basic energy saving algorithm; Aut=automatic energy saving algorithm.
HES	Differential for energy saving mode: (-30.0 to 30.0°C; -54 to 54°F) it sets the increasing value of the set point during the Energy Saving cycle.
LdE	Energy saving mode controls the lights (lights off when E.S. goes active): (n; Y) the light status depends on the energy saving mode and is managed from ErA.
Aid	Period of analysis for ErA (valid if ErA=Aut): (1 to 20 days) set the interval of time for temperature variation analysis.
StE	Period of time to switch from normal mode to energy saving mode (valid if ErA=bAS): (0.0 to 24h00min, res. 10 min) if door stay closed for StE time, the energy saving mode will be activated. NOTE: this will require a door switch to work.
EtS	Period of time to switch from energy saving to normal mode (valid if ErA=bAS): (0.0 to 24h00min, res. 10 min) maximum time for energy saving mode. NOTE: this will require a door switch to work.
dS	Door open time to switch from EtS to StE (valid if ErA=bAS): (0 to 999 sec) the energy saving mode will be immediately deactivated as soon as the door stays open more than the dS time. NOTE: this will require a door switch to work.
oHt	Overheating before activating the super cooling function (when in normal mode): (1.0 to 12.0°C; 1 to 21°F) this is the upper threshold limit used to activate the super cooling function.
SCo	Subcooling for Super Cooling function (when in normal mode): (0.0 to 12°C; 0 to 21°F) this is the special set-point value used during a super cooling function (cut-off value for compressor). If SCo=0, the super cooling function during normal mode is disabled.
tSC	Maximum duration for Super Cooling function (both for normal and energy saving mode): (0.0 to 24h00min, res. 10 min) maximum length for super cooling mode.
oHE	Overheating before activating the super cooling function (when in energy saving mode): (1.0 to 12.0°C; 1 to 21°F) this is the upper threshold limit used to activate the super cooling function.
SCE	Subcooling for Super Cooling function (when in energy saving mode): (0.0 to 12°C; 0 to 21°F) this is the special set-point value used during a super cooling function (cut-off value for compressor). If SCE=0, the super cooling function during energy saving mode is disabled.

**COUNTERS**

nH1	Number of compressor activation (thousands of) (read only)
nL1	Number of compressor activation (hundreds of) (read only)
nH4	Number of light activation (thousands of) (read only)
nL4	Number of light activation (hundreds of) (read only)
oCH	Compressor working hours (thousands of) (read only)
oCL	Compressor working hours (hundreds of) (read only)

**OTHER**

Adr	Serial address for Modbus communication: 0 to 247
onF	Button function: nu=not used; onF=ON/OFF function; ES=change working mode from normal to energy saving mode and vice-versa.
d1	Thermostat probe display (read only)
d2	Evaporator probe display (read only)
d4	Condenser probe display (read only)
rSE	Real Set point (read only)
rEL	Firmware Release (read only)
Ptb	Parameter code table (read only)
FdY	Firmware release information (read only).
FMt	Firmware release information (read only).
FYr	Firmware release information (read only).



**10 DIGITAL INPUT**

The free voltage digital input is programmable in different configurations by the **i1F** and **i2F** parameters.

**DOOR SWITCH (i1F=dor)**

It signals the door status and the corresponding relay output status through the **odC** parameter: **no** = normal (any change); **FAn** = not used; **CPr** = Compressor OFF; **F-C** = Compressor and fan OFF. Since the door is opened, after the delay time set through parameter **did**, the door alarm is enabled, the display shows the message “**dA**” and the **regulation restarts if rrd = Y**. The alarm stops as soon as the external digital input is disabled again. With the door open, the high and low temperature alarms are disabled.

**START DEFROST (i1F=dEF)**

It starts a defrost if there are the right conditions. After a defrost is finished, the normal regulation will restart only if the digital input is disabled otherwise the instrument will wait until the **MdF** safety time is expired.

**LIGHT CONTROL (i1F=LIG)**

The light output status will change with the digital input.

**ENERGY SAVING (i1F=ES)**

The energy saving mode will be enabled / disabled with the digital input.

**AUXILIARY OUTPUT (i1F=AUS)**

The AUX output (if present and configured) will be enabled / disabled with the digital input.


**EXTERNAL ALARM (i1F=EAL)**

It is used to detect an external alarm. This signal does not block the regulation.

**BLOCK ALARM (i1F=bAL)**

It is used to detect any critical external alarm. This signal blocks the regulation.

**11 INSTALLATION AND MOUNTING**



Instrument **XRBO7CX** shall be mounted on vertical panel, in a 29x71 mm hole, and fixed using the special bracket supplied. The temperature range allowed for correct operation is 0 to 60°C. Avoid places subject to strong vibrations, corrosive gases, excessive dirt or humidity. The same recommendations apply to probes. Let air circulate by the cooling holes.

**12 OPTIONAL FEATURES**



The **MDP/CX** rear cover can be used to increase the protection from water and dust.



The **HOT-KEY** is used for a quick and easy upload (from device to **HOT-KEY**) or download (from **HOT-KEY** to device) of the parameter map.



The **PROG-KEY** is used for firmware upgrade operations.



**WIZMATE PROG-TOOL KIT**

With this self-powered tool kit it is possible to easily modify the internal parameter map of any XRB device. The **WIZMATE@** software (part of this KIT) permits to build any personal configuration in a short time and to load it into the controller memory.

**13 ELECTRICAL CONNECTIONS**

The instrument is provided with screw terminal block to connect cables with a cross section up to 2.5mm². Before connecting cables make sure the power supply complies with the instrument's requirements. Separate the probe cables from the power supply cables, from the outputs and the power connections. Do not exceed the maximum current allowed on each relay, in case of heavier loads use a suitable external relay.

**13.1 PROBES**

The probes shall be mounted with the bulb upwards to prevent damages due to casual liquid infiltration. It is recommended to place the thermostat probe away from air streams to correctly measure the average room temperature. Place the defrost termination probe among the evaporator fins in the coldest place, where most ice is formed, far from heaters or from the warmest place during defrost, to prevent premature defrost termination.

**14 USE THE HOT KEY**

**14.1 SAVE PARAMETERS IN A HOT KEY (UPLOAD FROM INSTRUMENT)**

1. Program one controller with the front keypad.
2. When the controller is ON, insert the “**HOT-KEY**” and push **UP** button; the “**UP**” message appears followed a by flashing “**End**”

3. Push “**SET**” key and the “**End**” will stop flashing.
4. Turn OFF the instrument and then remove the “**HOT-KEY**”. At the end turn the instrument ON again.

**NOTE:** the “**Err**” message appears in case of a failed programming operation. In this case push again the **UP** button if you want to restart the upload again or remove the “**HOT-KEY**” to abort the operation.

**14.2 COPY PARAMETERS FROM A HOT KEY (DOWNLOAD PARAMETER VALUES)**

1. Turn OFF the instrument.
2. Insert a programmed “**HOT-KEY**” into the **5-PIN** receptacle and then turn the Controller ON.
3. Automatically the parameter list of the “**HOT-KEY**” is downloaded into the Controller memory, the “**do**” message is blinking followed a by flashing “**End**”.
4. After 10 seconds the instrument will restart working with the new parameters.
5. Remove the “**HOT-KEY**”.

**NOTE:** the message “**Err**” is displayed for failed programming. In this case turn the unit off and then on if you want to restart the download again or remove the “**HOT-KEY**” to abort the operation.

**15 USE THE PROG-KEY**

During 30 sec which following a switch on it will be possible to upgrade the internal firmware by using a special tool named **PROG-KEY**. This operation does not change the internal parameter configuration.

**PAY ATTENTION:** this operation **MUST** be carried out only from expert personnel in order not to damage the controller. Please contact you regional reseller to have more information.

**16 ALARM SIGNALLING**

Label	Cause	Outputs
“oFF”	Keyboard locked	Outputs unchanged
“on”	Keyboard unlocked	Outputs unchanged
“P1”	Room probe failure	Compressor output according to <b>Con e CoF</b>
“P2”	Evaporator probe failure	Defrost end is timed
“P4”	Fourth probe failure	Linked temperature alarm is not managed
“HA”	Maximum temperature alarm	Outputs unchanged
“LA”	Minimum temperature alarm	Outputs unchanged
“H2”	Maximum temperature for second temperature alarm	Outputs unchanged
“L2”	Minimum temperature for second temperature alarm	Outputs unchanged
“dA”	Door open more than <b>doA</b> time	Compressor and fans restarts
“EA”	External alarm	Outputs unchanged
“CA”	Serious external alarm	Outputs disabled
“EE”	EEPROM alarm	Outputs unchanged

**16.1 ALARM RECOVERY**


Probe alarms “**P1**”, “**P2**” and “**P4**” start some seconds after the fault in the related probe; they automatically stop some seconds after the probe restarts normal operation. Check connections before replacing the probe. Temperature alarms “**HA**”, “**LA**”, “**H2**” and “**L2**” automatically stop as soon as the temperature returns to normal values. It is possible to reset the “**EE**” alarm by pressing any button. The alarms “**EA**”, “**CA**” and “**dA**” will automatically stop as soon as the digital input is disabled. The optional buzzer can be muted by pressing any key if parameter **tbA=Y**.

**17 TECHNICAL DATA**

**Housing:** self-extinguishing ABS  
**Case:** frontal 32x74 mm; depth 60mm  
**Mounting:** panel mounting in a 71x29mm panel cut-out  
**Body Protection:** IP20  
**Frontal protection:** IP65  
**Connections:** Screw terminal block ≤ 2.5 mm² wiring  
**Power supply:** (according to the model) 230Vac ±10%, 50/60Hz; 110Vac ±10%, 50/60Hz  
**Power absorption:** 3.5VA max  
**Display:** 3 digits red LED, 14.2 mm high  
**Inputs:** up to 3 NTC probes.  
**Digital input:** free voltage contact.  
**Relay outputs:** Compressor SPST 16(5)A, 250VAC  
**Light:** SPDT 8(3)A, 250VAC  
**Data storing:** on the non-volatile memory (EEPROM)  
**Kind of action:** 1B  
**Pollution degree:** 2  
**Software class:** A  
**Rated impulsive voltage:** 2500V; **Overvoltage Category:** II  
**Operating temperature:** 0 to 60°C (32 to 140°F)  
**Storage temperature:** -25 to 60°C (-13 to 140°F)  
**Relative humidity:** 20 to 85% (no condensing)  
**Measuring and regulation range:**  
 NTC -40 to 110°C (-40 to 230°F)  
**Resolution:** 0.1°C or 1°C (selectable).  
**Accuracy (ambient temp. 25°C):** ±0.1°C ±1 digit.

18 CONNECTIONS

18.1 XRB04CX – 16+8 – 230VAC



19 APPLICATION NOTES

Pay attention to the positioning of the regulation probe. In fact, the XRB can obtain the best performances of the system under control when the regulation probe is placed by following these guidelines:

	<p><b>Ventilated applications – Evaporator placed on the back of the refrigerated zone, ventilator placed above the evaporator</b></p> <ul style="list-style-type: none"> <li>- The regulation probe is normally placed in the outlet air flow from the evaporator</li> <li>- The regulation probe can be placed both inside or outside the ventilator pack, paying attention to avoid positions too near to the motor of the ventilator</li> </ul>
	<p><b>Ventilated applications – Evaporator placed on the top side of the refrigerated zone, ventilator placed on the outlet air flow from the evaporator</b></p> <ul style="list-style-type: none"> <li>- The regulation probe is normally placed in the inlet air flow to the evaporator</li> <li>- The regulation probe has to be installed outside the evaporator, avoiding any contact with the metallic parts of the evaporator itself</li> </ul>
	<p><b>Static applications – Coolers without ventilators:</b></p> <ul style="list-style-type: none"> <li>- The regulation probe is normally placed at the side-wall of the refrigerated zone, approximately from 30% to 50% (of the internal height) from the bottom and 20% to 30% (of the internal width) from the back</li> </ul>

20 DEFAULT SETTING VALUES

LABEL	DESCRIPTION	RANGE	VALUE	LEV
SEt	Set Point	LS; US	3.0°C	---
HY	Differential in normal mode (energy saving not active)	[0.1 to 25°C] [1 to 45°F]	2.0°C	Pr1
HYE	Differential when energy saving active	[0.1 to 25°C] [1 to 45°F]	3.0°C	Pr1
LS	Minimum set point	[-55°C to SET] [-67°F to SET]	-50.0°C	Pr1
US	Maximum set point	[SET to 110°C] [SET to 230°F]	50.0°C	Pr1

ot	Thermostat probe calibration	[-12.0 to 12.0°C] [-21 to 21°F]	0.0	Pr1
P2P	Evaporator probe presence	n; Y	Y	Pr1
oE	Evaporator probe calibration	[-12.0 to 12.0°C] [-21 to 21°F]	0.0	Pr1
P4P	Fourth probe presence	n, Y	n	Pr2
o4	Fourth probe calibration	[-12.0 to 12.0°C] [-21 to 21°F]	0.0	Pr2
odS	Outputs delay activation after start up	0 to 255 min	1	Pr1
AC	Anti-short cycle delay	0 to 50 min	1	Pr1
Con	Compressor ON time with faulty probe	0 to 255 min	15	Pr2
CoF	Compressor OFF time with faulty probe	0 to 255 min	30	Pr2
CF	Temperature measurement unit	°C; °F	°C	Pr1
rES	Resolution (only for °C): decimal, integer	dE; in	dE	Pr1
Lod	Probe displayed	P1; P2; P3; P4; SEt; dtr; USr	P1	Pr2
dLY	Display temperature delay	0.0 to 20min00sec, res. 10 sec	0	Pr2
tdF	Defrost type: electrical heating, hot gas, compressor stop	EL, in; ALt	EL	Pr1
dFP	Probe selection for defrost control	nP; P1; P2; P3; P4	P2	Pr1
dtE	Defrost termination temperature for defrost control	[-55 to 50°C] [-67 to 122°F]	12.0°C	Pr1
idF	Interval between two consecutive defrost cycles	0 to 255 hours	8	Pr1
MdF	Maximum length for defrost	0 to 255 min	30	Pr1
dSd	Start defrost delay	0 to 255 min	0	Pr2
dFd	Displaying during defrost	rt; it; SEt; dEF; dEG	dEF	Pr1
dAd	Max delay for updating display after a defrost	0 to 255 min	1	Pr1
Fdt	Draining time	0 to 255 min	0	Pr1
dPo	First defrost after start-up	n; Y	n	Pr1
ALC	Temperature alarms configuration	rE, Ab	Ab	Pr1
ALU	Maximum temperature alarm	[ALL to 110.0°C] [ALL to 230°F]	50.0°C	Pr1
ALL	Minimum temperature alarm	[-55°C to ALU] [-67°F to ALU]	0.0°C	Pr1
AFH	Differential for temperature alarm recovery	[0.1 to 25.5°C] [1 to 45°F]	1.0°C	Pr1
ALd	Temperature alarm delay	0 to 255 min	0	Pr1
dAo	Delay of temperature alarm at start up	0.0 to 24h00min, res. 10 min	8.0	Pr1
AP2	Probe selection for second temperature alarms	nP; P1; P2; P3; P4	nP	Pr1
AL2	Second low temperature alarm	[-55.0 to 110.0°C] [-67 to 230°F]	0.0	Pr1
AU2	Second high temperature alarm	[-55.0 to 110.0°C] [-67 to 230°F]	110.0	Pr1
AH2	Differential for second temperature alarm recovery	[0.1 to 25.5°C] [1 to 45°F]	2.0	Pr1
Ad2	Second temperature alarm delay	0 to 254 min; 255=not used	0	Pr1
dA2	Delay for second temperature alarm at start up	0.0 to 24h00min, res. 10 min	1.3	Pr1
bLL	Compressor off because of second low temperature alarm	n; Y	n	Pr2
AC2	Compressor off because of second high temperature alarm	n; Y	n	Pr2
i1P	Digital input 1 polarity	CL; oP	CL	Pr1
i1F	Digital input 1 configuration	dor; dEF; LiG; AUS; ES	dor	Pr1
did	Digital inputs alarm delay	0 to 255 min	1	Pr2
doA	Door alarm delay	0 to 255 min	5	Pr1
odC	Compressor and fan status after opening of the door	no; FAn; CPPr; F-C	FAn	Pr2
rrd	Regulation restart after door open alarm	n; Y	Y	Pr2
ErA	Energy reduction algorithm used	nu; bAS; Aut	Aut	Pr2
HES	Differential for energy saving mode	-30 to 30°C	5.0°C	Pr1
LdE	Energy saving mode controls the lights (lights off when E.S. goes active)	n; Y	Y	Pr2
StE	Period of time to switch from normal mode to energy saving mode (valid if ErA=bAS)	0.0 to 24h00min, res. 10 min	4.0	Pr2
EtS	Period of time to switch from energy saving to normal mode (valid if ErA=bAS)	0.0 to 24h00min, res. 10 min	6.0	Pr2
dS	Door open time to switch from EtS to StE (valid if ErA=bAS)	0 to 999 sec	10	Pr2
oHt	Overheating before activating the super cooling function (when in normal mode)	[1.0 to 12.0°C] [1 to 21°F]	8.0°C	Pr1
SCo	Subcooling for Super Cooling function (when in normal mode)	[0.0 to 12.0°C] [0 to 21°F]	1.0°C	Pr1
tSC	Maximum duration for Super Cooling function (both for normal and energy saving mode)	0.0 to 24h00min, res. 10 min	0.20	Pr1
oHE	Overheating before activating the super cooling function (when in energy saving mode)	[1.0 to 12.0°C] [1 to 21°F]	0.0°C	Pr1
SCE	Subcooling for Super Cooling function (when in energy saving mode)	[0.0 to 12.0°C] [0 to 21°F]	0.0°C	Pr1
n1H	Number of compressor activation (thousands of)	Read Only	---	Pr2
n1L	Number of compressor activation (hundreds of)	Read Only	---	Pr2

<b>n4H</b>	Number of light activation (thousands of)	Read Only	---	Pr2
<b>n4L</b>	Number of light activation (hundreds of)	Read Only	---	Pr2
<b>oCH</b>	Compressor working hours (thousands of)	Read Only	---	Pr2
<b>oCL</b>	Compressor working hours (hundreds of)	Read Only	---	Pr2
<b>Adr</b>	Serial address	1 to 247	1	Pr2
<b>onF</b>	ONOFF button function	nu; onF; ES	onF	Pr2
<b>dP1</b>	Thermostat probe display	Read Only	---	Pr1
<b>dP2</b>	Evaporator probe display	Read Only	---	Pr1
<b>dP4</b>	Condenser probe display	Read Only	---	Pr1
<b>rSE</b>	Real Set point	Read Only	---	Pr1
<b>rEL</b>	Firmware release	Read Only	---	Pr1
<b>Ptb</b>	Parameter code table	Read Only	---	Pr1
<b>FdY</b>	Firmware date: day	Read Only	---	Pr1
<b>FMt</b>	Firmware date: month	Read Only	---	Pr1
<b>FYr</b>	Firmware date: year	Read Only	---	Pr1

Dixell™



Dixell S.r.l. - Z.I. Via dell'Industria, 27 - 32010 Pieve d'Alpago (BL) ITALY  
 Tel. +39.0437.9833 r.a. - Fax +39.0437.989313 - EmersonClimate.com/Dixell - dixell@emerson.com